



Thermocouple Process Calibrator

User's MANUAL

Safety Information

To avoid possible electric shock or personal injury:

- Never apply more than 30V between any two jacks, or between any jack and earth ground.
- Make sure the battery door is closed and latched before you operate the calibrator.
- Remove test leads from the calibrator before you open the battery door.
- Do not operate calibrator if it is damaged.
- Do not operate the calibrator around explosive gas, vapor, or dust.

To avoid possible damage the calibrator:

- Make sure choose the right jack and rang, before use the calibrator to measurement or calibrator.
- Take away the calibrator from the used circumstance, before operate the calibrator or after close the calibrator.

Introduction

Thermocouple Process Calibrator is a exactitude measurement and source handhold instrument, it can be use to calibrate the Thermocouple instrument.

Thermocouple Process Calibrator can measure or simulate 8 types of difference Thermocouple ($^{\circ}\text{C}$ or $^{\circ}\text{F}$), and measure or simulate the millivolt. But it could not use to measurement or source at a same time.

The accessories: 2 pcs Thermocouple plugs (no wire), 6 * AAA 1.5V battery, user's manual.

If the Calibrator is broken or short of some accessories, please contact the supplier.

The following table has showed the technical parameter and function of the Calibrator.

Specification

All the specification will under 1 year calibration cycle and temperature between 18~28°C, except addition explain.

Measure (input)/Simulate (output) Millivolt specification

INPUT/OUTPUT RANGE	RESOLUTION	ACCURACY
-10mV~100mV	0.01mV	± (0.025%+2counts)

Maximal input voltage: 30Vpp.

Measure (input) / Simulate (output) Thermocouple Specification

FUNCTION	RANGE	RESOLUTION	ACCURACY	REFERENCE JUNCTION ERROR
J TYPE	-200~1200°C / -328~2192°F	0.1°C/°F	$\pm(0.3^{\circ}\text{C}+10\mu\text{V}) /$ $\pm(32.54^{\circ}\text{F}+10\mu\text{V})$	$\pm 0.3^{\circ}\text{C} / \pm 32.54^{\circ}\text{F}$
K TYPE	-200~1370°C / -328~2498°F	0.1°C/°F	$\pm(0.3^{\circ}\text{C}+10\mu\text{V}) /$ $\pm(32.54^{\circ}\text{F}+10\mu\text{V})$	$\pm 0.3^{\circ}\text{C} / \pm 32.54^{\circ}\text{F}$
T TYPE	-200~400°C / -328 ~ 752°F	0.1°C/°F	$\pm(0.3^{\circ}\text{C}+10\mu\text{V}) /$ $\pm(32.54^{\circ}\text{F}+10\mu\text{V})$	$\pm 0.3^{\circ}\text{C} / \pm 32.54^{\circ}\text{F}$

Thermocouple Process Calibrator Manual

E TYPE	-200~950°C / -328~1742°F	0.1°C/°F	±(0.3°C+10uV) ±(32.54°F+10uV)	±0.3°C/ ±32.54°F
R TYPE	-20~1750°C / -4~3182°F	1°C/°F	±(1°C+10uV) ±(33.8+10uV)	±0.3°C/ ±32.54°F
S TYPE	-20~1750°C/ -4~3182°F	1°C/°F	±(1°C+10uV) ±(33.8+10uV)	±0.3°C/ ±32.54°F
B TYPE	600~1800°C / 1112~3272°F	1°C/°F	±(1°C+10uV) ±(33.8+10uV)	±0.3°C/ ±32.54°F
N TYPE	-250~1300°C / -418~2372°F	0.1°C/°F	±(0.3°C+10uV) ±(33.8+10uV)	±0.3°C/ ±32.54°F

Maximal input voltage: 30Vpp.

General Specifications:

Maximum voltage applied between any jack and earth ground or between any two jack: 30V

Storage temperature: $-40^{\circ}\text{C} \sim 60^{\circ}\text{C}$ ($-40^{\circ}\text{F} \sim 140^{\circ}\text{F}$)

Operating temperature: $0^{\circ}\text{C} \sim 50^{\circ}\text{C}$ ($32^{\circ}\text{F} \sim 122^{\circ}\text{F}$)

Operating altitude: 3000 meters maximum

Temperature coefficient: $\pm 0.02\%/^{\circ}\text{C}$ on $0^{\circ}\text{C} \sim 18^{\circ}\text{C}$ ($32^{\circ}\text{F} \sim 64.4^{\circ}\text{F}$)
and $28^{\circ}\text{C} \sim 50^{\circ}\text{C}$ ($82.4^{\circ}\text{F} \sim 122^{\circ}\text{F}$)

Relative humidity: 95% up to 30°C (86°F), 75% up to 40°C (104), 45% up to 50°C (122°F)

Shock: Random 2g, 5Hz to 500Hz

Safety: 1 meter drop test



Fuse: F 0.125A/250V




Power requirements: 6 x AAA 1.5V Battery

Size(LxWxH): 205mm×98mm×46mm (8.07×3.85×1.81 inch)

Weight: 472 g (include battery) (16.64 Ounces)

International Symbols


Symbol	Meaning
	Earth ground
	Conforms to European Union directives

	Refer to this instruction sheet for information about this feature.
	Battery
	Double insulation

Explanation on Front Panel

The front panel is show as in right figure:


1. Input / Output jack
2. Power key
3. Mode key
4. °C/°F key



5. Input/output key
6. Increase more value key
7. Reduce more value key
8. Increase less value key
9. Reduce less value key

Understanding Display Screen

LCD screen is shown as in following figure:





- | | |
|---|---------------------------------|
| 10. Input state indication | 15. Low power indication |
| 11. Output state indication | 16. Unit indication |
| 12. Indicating AUTO POWER OFF is availability | 17. Type indication |
| 13. Result value | 18. Ambient temperature display |
| 14. Calibration mode indication | |

Operation Instructions

Thermocouple or Millivolt measurement/input

- ① Press the power key², turn on the calibrator.
- ② Press the Input/output key⁵, When on the input mode.
- ③ Press mode key³, on the measure type you want.
- ④ Put the measure thermocouple or millivolt source into the input jack¹.

. 10 .





- ⑤ Get the reading value 13. In thermocouple measurement, ambient temperature value 18 is displayed on LCD. In voltage measurement, there is no temperature display.

* The number in the □, referring to the Explanation on Front Panel (Page8) and the Understanding Display Screen (Page9).

Thermocouple or Millivolt Simulate/output

- ① Press the power key 2, turn on the calibrator.
- ② Press the Input/output key 5, When on the output mode.
- ③ Press mode key 3, on the measure type you want.
- ④ Press the adjust value key 6 7 8 9 to let the value on your need.



- ⑤ Put the thermocouple instrument or voltage meter into the output jack **1**.
- ⑥ If you want to change the output value, then press the adjust value key **6** **7** **8** **9** or change to other thermocouple type use the mode key **3**.

Autopower OFF

Autopower off default setting is 30min.

Setting Autopower off option:

1. Keep press **4** °C/°F key, then turn on the power.
2. Release **4** °C/°F key, press **6** Increase more value key or **7** Reduce more value key to adjust the time.(off,15min.~60min.)
3. Then press **4** °C/°F key to finish setting autopower off option.

- *. After change battery the autopower off setting get to default setting.
- *. If change battery and found can not turn on power, please take off the battery, and wait 3min, then try again.

Display all symbol


Setting display all symbol:

1. Keep press **3** mode key, then turn on the power.
2. It will display all symbol on LCD.
3. Press any key exit and go on.

To use Adapter (Only apply to AC power adapter version calibrator)

Connecting the power adapter:

- 1, Connect the AC power cord to the AC—DC converter.
- 2, Plug the AC power cord into an electrical outlet(100V-240V).
- 3, Plug the DC power plug of the converter into DC power socket of the meter.



AC/DC adapter information:

Input: 100V-240VAC,50-60Hz 1.8A

Output :DC 12V 2A MAX

Polarity :



WARNING:

- 1,Please use the original AC power adapter, using other AC power adapter may damage your instrument.
- 2, The AC power adapter can only be used indoors.
- 3,Please plug the AC power cord into an electrical outlet first and then firmly insert DC plug into DC input end in the right of the meter. When unplugged, firstly pull out the DC plug perpendicular to DC input end and then unplug the AC plug from the electrical

outlet.

- 4, Do not use the AC power adapter in other equipment except this instrument.
- 5, In use, it is a normal phenomenon that the AC power adapter will be hot.
- 6, Do not demolish the AC power adapter. Otherwise, it may be dangerous.
- 7, Do not use the AC power adapter in a high temperature or wet place.
- 8, Please make the AC power adapter avoid a strong bump.
- 9, It is normal when the AC power adapter make some noise in use.

Maintenance

Cleaning

Periodically wipe the case with a damp cloth and detergent; do not use abrasives or solvents.

Calibration

Calibrate your calibrator once a year to ensure that it performs according to its specifications.

Replacing the Battery

Please change the battery when the LCD indicates 

Turn off the power of the Calibrator, When you change the battery, and screw off the breechblock on the battery cabinet cover, then take off it and instead the fresh battery.

Replacing a Fuse

 **Warning!**

To avoid personal injury or damage to the calibrator, use only a 0.125A 250V fast fuse.

In the thermocouple input mode, if 'OL' does not appears on LCD with no thermocouple input, the fuse is probably blown. A new fuse should be used.

Connect wire

Use the accessories thermocouple plug to make the difference plug connect wire which you want.

Sifam Tinsley Instrumentation Inc.

2105 Barrett Park Drive, Unit 105, Kennesaw, GA 30144

Contact No. : +1 678 881 0008

E-mail Id : psk@sifamtinsley.com

Web : www.sifamtinsley.com
