





**Commonly Used codes for TT20-**

TT20- I74F2DRZ00000	Current; Input: 1-5A AC; Aux: 24-60VACDC; 2Output; Display; RS485
TT20- 174H2DRZ00000	Current; Input: 1-5A AC; Aux: 60-300VACDC; 2Output; Display; RS485
TT20- V8EF2DRZ00000	Voltage; Input: 57-500V AC; Aux: 24-60VACDC; 2Output; Display; RS485
TT20- V8EH2DRZ00000	Voltage; Input:57-500V AC; Aux: 60-300VACDC; 2Output; Display; RS485

