



**Part Number
Coding Booklet**

Theta Series -TT20

Theta 20A/20V- Current and Voltage Transducer

Product Code	TT20-	X	XX	X	X	X	X	X	XXXXX
Product Type	Theta 20A	I	74	H	1	D	R	C	00000
	Theta 20V	V							
Input Range	Prog. 1...5A 1-5A								
	Prog. 57...500V 57-500V	8E							
Power Supply	60-300V AC/DC		F						
	24-60V AC/DC								
Output	1 O/P 10			2					
	2 O/P 20								
Display Module	With Display D			Z					
	Without Display WD								
RS 485 Module	With RS-485 485								
	Without RS-485								
Prog. Cable	With PRKAB 601 PRK				Z				
	Without PRKAB 601								
Version	Standard								

Commonly Used codes for TT20-

TT20-I74F2DRZ00000	Current; Input: 1-5A AC; Aux: 24-60VACDC; 2Output; Display; RS485
TT20-174H2DRZ00000	Current; Input: 1-5A AC; Aux: 60-300VACDC; 2Output; Display; RS485
TT20-V8EF2DRZ00000	Voltage; Input: 57-500V AC; Aux: 24-60VACDC; 2Output; Display; RS485
TT20-V8EH2DRZ00000	Voltage; Input:57-500V AC; Aux: 60-300VACDC; 2Output; Display; RS485



Email: psk@sifamtinsley.com | Web: www.sifamtinsley.com

Phone: 404.736.4903 | Fax: +1 678 881 0008 x 701 | Toll Free: 800 879 6171

3105 Creekside Village Dr, Unit 801, Kennesaw GA 30144