





**Commonly Used Ranges for Theta HZ-**

TT25- 78FF2DRZ00000	HZ 45-65; Input: 100-500V AC; Aux: 24-60VACDC; 2Output; Display; RS485
TT25- 78FH2DRZ00000	HZ 45-65; Input: 100-500V AC; Aux: 60-300VACDC; 2Output; Display; RS485

